



Parata PASS™ 36 Pouch Packager

Key Features

Scalability: Smart canisters extend capacity beyond the standard configuration. Store additional canisters outside the unit and swap them in as needed.

Intuitive Software: Parata PASS Ware® software is flexible and easy to use. It offers a wide range of reporting, a drag-and-drop editor to customize pouch design, and the ability to include header, footer, and reminder pouches.

Capacity

Up to 36 canisters (or unique NDCs) at one time

Pharmacy Software Integrations

Parata integrates with nearly 100 host systems

Included with your Purchase of a Parata PASS Packager

- Canisters (36) and canister labels
- Canister build kit
- Special tablet trays (3)
- Laser printer (1) and Dymo printer (1)
- Precisa LS 2200C Scale
- Cleaning kit
- PASS pack boxes, assorted
- Paper (3 rolls) and ribbon
- Parata PASS Ware license and workstations, which includes: standard PC tower, 22-inch widescreen monitor, keyboard, mouse, printer, and barcode scanner

Optional Complements

- Parata Perl® Pouch Inspector
- iRolly, Winder DE

Network Requirements

Ethernet RJ-45 (Cat VI)

Power/Space Requirements

PASS Packager: One dedicated 120V / 60Hz outlet within 6 feet of the packager.
PASS Ware Workstation: Connection to uninterruptable power supply (UPS) and access to 120V / 15A / 60Hz outlets.
Workstation must be located within 6 feet of the unit. Unit requires a direct connection to the workstation.

Parata PASS™ 36 Pouch Packager

Increase your capacity by storing more NDCs in additional smart canisters.



Maximize a small space while building your program.

Create custom pouch designs by patient or facility.


Manage one-off meds, OTCs, half tabs, and more with STS trays.



Ensure a match between the drug and smart canister with barcode scanning.




Roll it into your pharmacy through a standard door frame.



Expect flexibility and control with easy-to-use software.

Retrieve PASS strips easily after packaging.



| Dimensions | Width (in) | Height (in) | Depth (in) |
|-------------|------------|-------------|------------|
| Packager | 37.4 | 66.5 | 21.3 |
| Total Space | 65.4 | 80.5 | 65.3 |

You'll also need counter space for the PASS Ware workstation.

| Weight | Unloaded (lb) | Loaded (lb) |
|----------|---------------|-------------|
| Packager | 386 | 405+ |